## High impact tank cleaning machine PressureClean Series 5TP




M12 plug

## **Features:**


- Intensive cleaning with little water and high pressure
- Ideal for small tanks with the most persistent soiling
- Driven by an efficient 24 V motor
- "IP 65" certified motor housing
- Scope of delivery: - PressureClean
  - 5 m cable with matching plug and open cable end
  - Not included: power supply unit for power supply with 24 VDC/1.1 A



Series 5TP



Туре	Dimensions [mm]				
	L <sub>1</sub>	L <sub>2</sub>	L <sub>3</sub>		
5TP.xx9.1Y.01	566	250	219		
5TP.xx9.1Y.02	816	500	469		
5TP.xx9.1Y.03	1,310	889	858		



Insertion diameter and interference circle diameter



Material Process side:

Max. tank diameter

The specified maximum tank

decisive for the cleaning result.

diameter applies to the recommended

operating pressure and is indicative only. The type of soiling is also

Stainless steel 316L, PTFE with carbon, PEEK, SI<sub>3</sub>N<sub>4</sub>, EPDM



Recommended operating pressure 100 bar

Max. temperature





Bearing Ball bearing

Filtration

Line strainer with a mesh size of 0.1 mm/170 Mesh

Max. tank diameter Max. tank diameter for most persistent soiling for medium soiling Туре [m] [m] 5TP.469.1Y 1.0 2.5 5TP.589.1Y 12 3.0 5TP.659.1Y 1.4 3.5




**Function video** www.lechler.com/de-en/medialibrary/videos-general-industry Or scan the QR code.



## Adapter for IBC containers:

- Suitable for all types of PressureClean
- Fits into a G 2 female thread
- Scope of delivery:
  - Adapter with Tri-Clamp as interface for PressureClean
  - IBC cover (DN 150, thread S165 x 7) made of HDPE
  - Stainless steel joint clamp with EPDM seal





Ordering no.: 05T.P30.00.00.00

Spray	Ordering no.				V water [l/min]		
angle	Туре	Lance length			v water [i/min]		
		1,000 [mm]			p [bar] (p <sub>max</sub> = 200 bar)		
		250 500 w [mm] [mm]	with adjustable flange	50	100	150	
360°	5TP.469.1Y	01	02	03	7	10	12
	5TP.589.1Y	01	02	03	14	20	24
	5TP.659.1Y	01	02	03	21	30	37

## Information on operation

• The electric motor may only be switched on when liquid is flowing through the nozzle.

Ordering	Туре	+	Lance length	=	Ordering no.
example:	5TP.469.1Y	+	01 :	=	5TP.469.1Y.01